

Front Hinge

PLATINUM SERIES CANOPY CAP

Our cover is designed to be a light weight, compact, reflective shade cover for use when rigging and while waiting on the grid. The strapless design allows easy access and your cockpit is always shaded and cool.

When you are ready for take off, slip the cover off and stow it in the included storage bag, in the glider while you fly.

The light weight design is not meant for extended use outdoors. It is not a replacement for a heavyweight, all weather cover. Do not use it while trailering as it won't allow the canopy to be locked.

HOW TO USE YOUR NEW CANOPY CAP:

Find the care label near the center seam. This is the front of the canopy cover.

Place the rear of the cover over the back of your raised canopy and hook the elastic around both rear corners.

Pull the cover forward and hook the elastic around the front of the canopy and at both front corners.

Straighten the center seam to align down the middle of the canopy and adjust any wrinkles along the sides until smooth.

You can now raise and lower your canopy at will during set up and while on the grid. There are no inconvenient straps to get in the way!